

Note: for those who prefer front side/back side tatting the text in italics and red indicates where the worker needs to use the second half of the ds first. Please ignore if you don't want to use that method.

Abbreviations

R	ring	vsp	Very small picot
Cl	close	P or -	picot
Fp	False picot (small BTS space)		
Still using Sh1 – continue			

SR34: 6 / 6 Cl
SR35: 3 + (R28) 3 – 3 / 3 Cl
SR36: Fp 3 vsp 1 / Fp 4 Cl
R37: 1 + (vsp SR36) 3 – 3 vsp 1 Cl
SR38: 1 + (R37) 3 / 4 Cl




Fig. 7

[Link to TIAS blog.](#)